Shaper

SHAPER DUO







- Hexagon Socket
- **■**Square Socket
- Now available for Hexalobular(6-lobe) Socket
- Perfect fit for back spindle of Swiss machine
- Achieves good corner edge sharpness
- Less tool pressure than Rotary-Broaching
- Easy to adjust for correct dimension
- Economical double-ended insert bar (Except for Hexalobular)

Comparison Chart of Hexalobular Socket Machining

	Tool Pressure	Cycle Time	Tool Cost	High speed spindle	Program	
Shaper Duo		0		Not necessary	Simple	No high speed spindle neededA lot less cycle time
End milling	0	×	\triangle	Necessary	Complicated	Need high speed spindleTime consuming process

- Small diameter endmill driven by high-speed spindle is popular way to create Hexalobular(6-lobe) socket. It has some flexibility but needs high speed spindle unit and it is a time consuming process.
- SHAPER DUO can make Hexalobular(6-lobe) socket faster and simpler.

Comparison Chart of HEX Socket Machining


	Tool Pressure	Cycle Time	Flexibility	Tool Cost	
Shaper Duo		* Can be off-set by over-wrapping operation	0		 Less tool pressure-especially on small diameter parts One size can cover several socket sizes
Broach Tool		\bigcirc	×		 Need to have tools for each socket size

- Rotary-broach is an efficient way for Hexagon socket.
 But tool pressure is high and often times it pushes part too hard.
- SHAPER DUO system enables less tool pressure and provides better tolerance with less cost.




Process Chart

(1) Center drilling




Make a center hole which is smaller than pilot hole drill.

(4) Chamfering



Chamfer with the same pilot hole drill as ①

2 Drilling (Pilot hole)




Select a drill with same or smaller (0 \sim -0.1mm) dia. as AF and machine a bit deeper because burrs may cause chipping on shaper insert

(5) Deburring



Finish and deburr with the same drill as in process² ☆Reduce cutting conditions due to heavy interruption

3 Shaper tool



Machine socket rotating 60 degrees 6 times

SHAPER DUO Process Chart -Hexalobular-

				Nu	mber of pas	ses	Estimated cycle time *			
Socket Size	Socket Size Tool		Starting "X" position	Final "X" position (mm)	Roughing pass 0.025mm	Finishing pass 0.005mm	ISO10664 Stadard depth of Hexalobular hole (mm)	Whole process	Process ⁴ Shaper	
T6	SSP050N25T06	(mm) 1.15	1.14	1.75	13	1	1.82	51 sec	23.2 sec	
T7	SSP050N31T07	1.38	1.35	2.06	15	1	2.44	59 sec	28.2 sec	
T8	SSP050N36T08	1.62	1.59	2.40	17	1	3.05	67 sec	33.8 sec	
T10	SSP050N41T10	1.92	1.89	2.80	19	1	3.56	75 sec	39.5 sec	
T15	SSP050N43T15	2.30	2.29	3.35	22	1	3.81	84 sec	46.2 sec	
T20	SSP050N46T20	2.71	2.69	3.95	26	1	4.07	94 sec	55.4 sec	
T25	SSP050N50T25	3.13	3.09	4.50	29	1	4.45	105 sec	63.8 sec	
T27	SSP050N55T27	3.52	3.51	5.07	32	1	4.70	115 sec	71.8 sec	
T30	SSP050N55T30	3.91	3.89	5.60	35	1	4.95	125 sec	80.2 sec	

^{*}Using Carbide drill

Feed: 3000 mm/min

DOC: 0.025 mm (Roughing), 0.005 mm (Finishing)

SHAPER DUO Process Chart -Hexagonal-

				Nu	mber of pas	ses	Estimated cycle time *			
HEX Standard	Tool	Pilot bore Dia.	Dia. position		Roughing pass 0.025mm	Finishing pass 0.005mm	ISO 2936 standard depth of Hex hole (mm)	Whole process	Process ⁴ Shaper	
HEX 1.5	SSP020N1130H	1.5	1.47	1.73	6	1	2	39 sec	14 sec	
HEX 2.0	SSP020N1430H	2.0	1.95	2.31	8	1	2.5	44 sec	16 sec	
HEX 2.5	SSP030N1940H	2.5	2.48	2.89	9	1	3	50 sec	20 sec	
HEX 3.0	SSP030N1940H	3.0	2.95	3.46	11	1	3.5	55 sec	23 sec	
HEX 4.0	SSP040N2450H	4.0	3.96	4.62	14	1	5	73 sec	33 sec	
HEX 5.0	SSP050N3260H	5.0	4.96	5.77	17	1	6	90 sec	46 sec	
HEX 6.0	SSP060N42120H	6.0	5.97	6.93	20	1	8	117 sec	63 sec	
HEX 8.0	SSP080N62160H	8.0	7.98	9.24	26	1	10	155 sec	92 sec	

^{*}Pilot bore diameter is same or smaller(0-0.1mm) as AF. *Shaper cutting conditions

Feed: 3000 mm/min


DOC: 0.025 mm (Roughing), 0.005 mm (Finishing)

Recommended Cutting Conditions

Feed: 3000 mm/min

DOC: Roughing ··· 0.025 mm + Finishing ··· 0.005 mm


Program Example → J6 · J7



^{*}Shaper cutting conditions

^{*}Using Carbide drill

Insert Bar -Hexalobular-




		Hexalobular Socket			D _s	,	a,	0	£	Pilot Roro Dia	Coated Carbide
Item Number	Socket Size	#	Α	В	D _s	L 2	α	β	· /	PILOL DOTE DIA	Coaled Carbide
		#	(mm)	(mm)	(mm)	(mm)	(mm)	(mm)	(mm)	(mm)	TM4
SSP050N25T06	T6	6	1.75	1.27	φ5	2.5	1.08	1.09	2.4	φ1.15	
SSP050N31T07	T7	_	_	-	φ 5	3.1	1.27	1.29	2.4	φ1.38	•
SSP050N36T08	T8	8	2.4	1.75	φ 5	3.6	1.48	1.50	2.4	φ1.62	
SSP050N41T10	T10	10	2.8	2.05	φ 5	4.1	1.67	1.70	2.4	φ1.92	•
SSP050N43T15	T15	15	3.35	2.4	φ 5	4.3	2.04	2.10	2.4	φ 2.30	
SSP050N46T20	T20	20	3.95	2.85	φ5	4.6	2.41	2.50	2.4	φ 2.71	•
SSP050N50T25	T25	25	4.5	3.25	φ 5	5.0	2.78	2.90	2.4	φ3.13	
SSP050N55T27	T27	-	_	-	φ 5	5.5	3.15	3.30	2.4	φ3.52	•
SSP050N55T30	T30	30	5.6	4.05	φ5	5.5	3.52	3.70	2.4	φ3.91	

**Caution: Due to the tolerance, it might not fit into the holder which is made by other company.

Sleeves → K8 · K9

Insert Bar -Hexagon-




Item Number	Base AF	HEX Standard size range	AF range	D _s	L ₁	L ₂	h₁	α	β	f	Coated Carbide
	(mm)	(mm)	(mm)	(mm)	(mm)	(mm)	(mm)	(mm)	(mm)	(mm)	TM4
SSP020N1130H	HEX 1.5	HEX 1.5 - 2.0	1.4 - 2.0	φ2	50	3.0	1.8	1.1	0.8	0.40	
SSP020N1430H	HEX 2.0	HEX 2.0 - 2.5	1.9 - 2.6	φ2	50	3.0	1.8	1.4	1.1	0.55	
SSP030N1940H	HEX 3.0	HEX 2.5 - 3.5	2.4 - 3.6	φ3	50	4.0	2.8	1.9	1.6	0.8	
SSP040N2450H	HEX 4.0	HEX 3.5 - 4.5	3.4 - 4.6	φ4	60	5.0	3.8	2.4	2.6	1.3	
SSP050N3260H	HEX 5.0	HEX 4.5 - 6.0	4.4 - 6.2	φ5	70	6.0	4.8	3.2	3.4	1.70	
SSP060N42120H	HEX 6.0	HEX 6.0 - 8.0	5.9 - 8.2	φ6	80	12.0	5.6	4.2	4.0	2.00	
SSP080N62160H	HEX 8.0	HEX 8.0 - 12.0	7.9 - 12.2	φ8	80	16.0	7.6	6.2	4.7	2.35	

%Caution: Due to the tolerance, it might not fit into the holder which is made by other company.

Sleeves → K8 · K9

Insert Bar -Square-



Item Number	Base AF	AF range	D _s	L 1	L2	h ₁	α	β	f	Coated Carbide
	(mm)	(mm)	(mm)	(mm)	(mm)	(mm)	(mm)	(mm)	(mm)	TM4
SSP020N1740S	2.0	1.9 - 2.3	φ2.0	50	4.0	1.8	1.70	1.60	0.70	•
SSP025N1940S	2.5	2.2 - 2.6	φ2.5	50	4.0	2.3	1.95	1.80	0.65	•
SSP030N2260S	3.0	2.5 - 3.0	φ3.0	50	6.0	2.8	2.20	2.05	0.65	•
SSP035N2760S	3.5	2.9 - 3.7	φ3.5	60	6.0	3.3	2.70	2.25	0.60	•
SSP040N3380S	4.0	3.6 - 4.6	φ4.0	60	8.0	3.8	3.35	3.05	1.15	•
SSP050N39100S	5.0	4.5 - 5.4	φ5.0	70	10.0	4.8	3.90	3.95	1.55	•
SSP060N47120S	6.0	5.3 - 6.6	φ6.0	80	12.0	5.6	4.75	4.50	1.70	•
SSP080N58160S	8.0	6.5 - 8.1	φ8.0	80	16.0	7.6	5.80	5.50	1.70	

**Caution: Due to the tolerance, it might not fit into the holder which is made by other company.

Sleeves → K8 · K9



SHAPER DUO Set-up Instructions - Hexagonal

Outside machine





- Set the insert bar in the sleeve and check the parallelism of the flat portion of the sleeve and the insert bar.
- Minimize the overhang of the insert.

Inside machine



- Set the sleeve into the tool post and make sure the sleeve is set parallel.
- Minimize sleeve overhang.





- Increase the number of machining passes with smaller depth of cut if the insert chips with large depth of cut. (0.025mm×5pass is recommended)
- No chamfering process is required for measuring purpose.
- Measure the length of both [a] and [b] with comparator or magnifier.
- Adjust centerline height by rotating the sleeve until you get the same length for [a] and [b]. (The difference should be less than 0.02mm)
- *If the straight is not seen with increased passes, please reset the insert and the sleeve.
- Please make sure both the insert and the sleeve are set up correctly.

4 Machine Hexagonal shape

Run full HEX machining program.



For Hexalobular machining Basically same as Hexagonal socket

